

## Dräger PARAT® 3000 Filtering Escape Devices

When hazardous substances are present at a work place it has to be taken into account that these substances can suddenly leak out into the air in concentrations that cause severe health impairment or even death.



The filtering escape devices Dräger PARAT 3000 have a single but vital task to perform: They ensure that the user is provided with protection along his escape route into a safe, breathable atmosphere. Therefore these devices are robust, compactly designed and safe and easy to handle. The filtering escape devices are designed for a minimum of 15 minutes of escape time and approved to the only standard world-wide for industrial escape devices (DIN 58647-7).

### Dräger PARAT® 3100:

Half mask with 2-point harness – quick donning, comfortable use and good communication

### Dräger PARAT® 3200:

Mouth piece/nose clip assembly – for very low leakage

### Benefits

- ABEK 15 Filter – protection against a wide range of toxic gases and vapours
- Robust, ergonomic case – for long service life even in rough work environments
- Transparent cover with mounting clip – easy to service and carry along for daily use
- Long service life - 12 years total life time (filter change every 4 years)



ST-1859-2005

Dräger PARAT® 3100



ST-1850-2005

Dräger PARAT® 3200

### TECHNICAL DATA

Filter performance	ABEK 15 gas filter for protection against organic and anorganic gases and vapours, approved in accordance to DIN 58647 part 7
Duration of use	at least 15 minutes
Shelf life	4 years maintenance free, filter exchange every 4 years, total shelf life 12 years
Weight	Dräger PARAT 3100 approx. 360g Dräger PARAT 3200 approx. 330g
Dimensions (L x W x H)	Dräger PARAT 3100 170 x 110 x 90mm Dräger PARAT 3200 170 x 110 x 60mm
Approval	approved in accordance to DIN 58647 part 7 (CE mark 0158)

## TECHNICAL DATA

### Filter capacity according to DIN 58647-7\*

Type	Test gas	Concentration in ml/m <sup>3</sup>	Breakthrough in ml/m <sup>3</sup>	Minimum breakthrough time in min
A	Cyclohexane (C <sub>6</sub> H <sub>12</sub> )	2,500	10	15
B	Chlorine (Cl <sub>2</sub> )	2,500	0.5	15
B	Hydrogen sulphide (H <sub>2</sub> S)	2,500	10	15
B	Hydrogen cyanide (HCN)	2,500	10	15
E	Sulphur dioxide (SO <sub>2</sub> )	2,500	5.0	15
K	Ammonia (NH <sub>3</sub> )	2,500	25	15
B	Hydrogen sulphide (H <sub>2</sub> S)	10,000*	20	5

\* Test conditions according to DIN 58647-7: 30 L/min, 70% relative humidity, 20°C.

\*) To determine the breakthrough capacity of the gas filter it is additionally tested with 10,000 ml/m<sup>3</sup> hydrogen sulphide.

## ORDER INFORMATION

Dräger PARAT 3100 Halfmask with ABEK 15 filter	R 57 981
Dräger PARAT 3200 Mouthbit with noseclip with ABEK 15 filter	R 57 982
<b>Upgrade Kits (excluding filter)</b>	
Dräger parat 1 to Dräger PARAT 3100	R 56 324
Dräger parat 2 to Dräger PARAT 3200	R 56 325
<b>Accessories:</b>	
Training device components	
PARAT 3100, housing cover (blue)	R 56 353
PARAT 3200, housing cover (blue)	R 56 354
<b>Replacement Filters</b>	
ABEK 15 replacement filter (PU 5 pieces)	R 57 983
PARAT 3000 security tag, 50 pieces each	R 56 355

### HEADQUARTERS

Dräger Safety AG & Co. KGaA  
Revalstrasse 1  
23560 Lübeck, Germany  
[www.draeger.com](http://www.draeger.com)

### SUBSIDIARIES

#### AUSTRALIA

Draeger Safety Pacific Pty. Ltd.  
Acess Corporate Park  
Unit 99, 45 Gilby Road  
Mt. Waverley Vic 3149  
Tel +61 3 92 65 50 00  
Fax +61 3 92 65 50 95

#### CANADA

Draeger Safety Canada Ltd.  
7555 Danbro Crescent  
Mississauga, Ontario L5N 6P9  
Tel +1 905 821 8988  
Fax +1 905 821 2565

#### P. R. CHINA

Beijing Fortune Draeger Safety  
Equipment Co., Ltd.  
A22 Yu An Rd, B Area,  
Tianzhu Airport Industrial Zone,  
Shunyi District, Beijing 101300  
Tel +86 10 80 49 80 00  
Fax +86 10 80 49 80 05

### FRANCE

Dräger Safety France SAS  
3c route de la Fédération,  
BP 80141  
67025 Strasbourg Cedex 1  
Tel +33 3 88 40 59 29  
Fax +33 3 88 40 76 67

### MEXICO

Draeger Safety S.A. de C.V.  
Av. Peñuelas No. 5 Bodega No. 37  
Fraccionamiento Industrial  
San Pedrito  
Querétaro, Qro México  
Tel +52 442 246-1113  
Fax +52 442 246-1114

### NETHERLANDS

Dräger Safety Nederland B.V.  
Edisonstraat 53  
2700 AH Zoetermeer  
Tel +31 79 344 46 66  
Fax +31 79 344 47 90

### REP. OF SOUTH AFRICA

Dräger South Africa (Pty) Ltd.  
P.O.Box 68601  
Bryanston 2021  
Tel +27 11 465 99 59  
Fax +27 11 465 69 53

### SINGAPORE

Draeger Safety Asia Pte Ltd  
67 Ayer Rajah Crescent  
#06-03  
Singapore 139950  
Tel +65 68 72 92 88  
Fax +65 65 12 19 08

### SPAIN

Dräger Safety Hispania S.A.  
Calle Xaudaró 5  
28034 Madrid  
Tel +34 91 728 34 00  
Fax +34 91 729 48 99

### UNITED KINGDOM

Draeger Safety UK Ltd.  
Blyth Riverside Business Park  
Blyth, Northumberland  
NE24 4RG  
Tel +44 1670 352-891  
Fax +44 1670 356-266

### USA

Draeger Safety, Inc.  
101 Technology Drive  
Pittsburgh, PA 15275  
Tel +1 412 787 8383  
Fax +1 412 787 2207